

Manufacturer	Model	System	Ecu	Ecu name	Feature	FeatureID	Detail
Rover	25	Engine Diesel	20T 2.0 EDC 15M		Live Parameters	1	Airflow sensor supply
Rover	25	Engine Diesel	20T 2.0 EDC 15M		Live Parameters	2	EGR vacuum modulator
Rover	25	Engine Diesel	20T 2.0 EDC 15M		Live Parameters	3	Accelerator pedal position sensor; power supply
Rover	25	Engine Diesel	20T 2.0 EDC 15M		Live Parameters	4	Engine speed
Rover	25	Engine Diesel	20T 2.0 EDC 15M		Live Parameters	5	Engine speed signal, injection pump
Rover	25	Engine Diesel	20T 2.0 EDC 15M		Live Parameters	6	Road speed signal
Rover	25	Engine Diesel	20T 2.0 EDC 15M		Live Parameters	7	Idle speed, target value
Rover	25	Engine Diesel	20T 2.0 EDC 15M		Live Parameters	8	Airflow
Rover	25	Engine Diesel	20T 2.0 EDC 15M		Live Parameters	9	EGR target air flow
Rover	25	Engine Diesel	20T 2.0 EDC 15M		Live Parameters	10	EGR valve opening
Rover	25	Engine Diesel	20T 2.0 EDC 15M		Live Parameters	11	Injection quantity (requested by driver)
Rover	25	Engine Diesel	20T 2.0 EDC 15M		Live Parameters	12	Calculated fuel quantity
Rover	25	Engine Diesel	20T 2.0 EDC 15M		Live Parameters	13	Actual fuel quantity
Rover	25	Engine Diesel	20T 2.0 EDC 15M		Live Parameters	14	Fuel quantity limit for current engine conditions
Rover	25	Engine Diesel	20T 2.0 EDC 15M		Live Parameters	15	Fuel quantity smoke limit
Rover	25	Engine Diesel	20T 2.0 EDC 15M		Live Parameters	16	Fuel quantity idle control limit
Rover	25	Engine Diesel	20T 2.0 EDC 15M		Live Parameters	17	AC switch
Rover	25	Engine Diesel	20T 2.0 EDC 15M		Live Parameters	18	AC compressor
Rover	25	Engine Diesel	20T 2.0 EDC 15M		Live Parameters	19	Evaporator, air conditioning
Rover	25	Engine Diesel	20T 2.0 EDC 15M		Live Parameters	20	Refrigerant pressure, A/C
Rover	25	Engine Diesel	20T 2.0 EDC 15M		Live Parameters	21	A/C request fan speed
Rover	25	Engine Diesel	20T 2.0 EDC 15M		Live Parameters	22	A/C actual fan speed
Rover	25	Engine Diesel	20T 2.0 EDC 15M		Live Parameters	23	A/C idle speed setpoint
Rover	25	Engine Diesel	20T 2.0 EDC 15M		Live Parameters	24	Idle switch
Rover	25	Engine Diesel	20T 2.0 EDC 15M		Live Parameters	25	Diagnosis lamp
Rover	25	Engine Diesel	20T 2.0 EDC 15M		Live Parameters	26	Brake switch
Rover	25	Engine Diesel	20T 2.0 EDC 15M		Live Parameters	27	Glow time lamp
Rover	25	Engine Diesel	20T 2.0 EDC 15M		Live Parameters	28	Glowplug relay
Rover	25	Engine Diesel	20T 2.0 EDC 15M		Live Parameters	29	Battery voltage
Rover	25	Engine Diesel	20T 2.0 EDC 15M		Live Parameters	30	Accelerator pedal position sensor
Rover	25	Engine Diesel	20T 2.0 EDC 15M		Live Parameters	31	Accelerator pedal position sensor
Rover	25	Engine Diesel	20T 2.0 EDC 15M		Live Parameters	32	Coolant temperature
Rover	25	Engine Diesel	20T 2.0 EDC 15M		Live Parameters	33	Inlet air temperature
Rover	25	Engine Diesel	20T 2.0 EDC 15M		Live Parameters	34	Inlet manifold pressure
Rover	25	Engine Diesel	20T 2.0 EDC 15M		Live Parameters	35	Atmospheric pressure
Rover	25	Engine Diesel	20T 2.0 EDC 15M		Live Parameters	36	Fuel temperature
Rover	25	Engine Petrol	11K4 1.1 Mems 3		ECU Information	1	Ignition coil 1
Rover	25	Engine Petrol	14K4 1.4 Mems 3		ECU Information	1	Ignition coil 1
Rover	25	Engine Petrol	16K4 1.6 Mems 3		ECU Information	1	Ignition coil 1
Rover	25	Engine Petrol	18K4 - VVC 1.8 Mems 3		ECU Information	1	Ignition coil 1
Rover	25	Engine Petrol	18K4 1.8 Mems 3		ECU Information	1	Ignition coil 1
Rover	45	Engine Diesel	20T 2.0 EDC 15M		Live Parameters	1	Airflow sensor supply
Rover	45	Engine Diesel	20T 2.0 EDC 15M		Live Parameters	2	EGR vacuum modulator
Rover	45	Engine Diesel	20T 2.0 EDC 15M		Live Parameters	3	Accelerator pedal position sensor; power supply
Rover	45	Engine Diesel	20T 2.0 EDC 15M		Live Parameters	4	Engine speed
Rover	45	Engine Diesel	20T 2.0 EDC 15M		Live Parameters	5	Engine speed signal, injection pump
Rover	45	Engine Diesel	20T 2.0 EDC 15M		Live Parameters	6	Road speed signal
Rover	45	Engine Diesel	20T 2.0 EDC 15M		Live Parameters	7	Idle speed, target value
Rover	45	Engine Diesel	20T 2.0 EDC 15M		Live Parameters	8	Airflow
Rover	45	Engine Diesel	20T 2.0 EDC 15M		Live Parameters	9	EGR target air flow
Rover	45	Engine Diesel	20T 2.0 EDC 15M		Live Parameters	10	EGR valve opening
Rover	45	Engine Diesel	20T 2.0 EDC 15M		Live Parameters	11	Injection quantity (requested by driver)
Rover	45	Engine Diesel	20T 2.0 EDC 15M		Live Parameters	12	Calculated fuel quantity
Rover	45	Engine Diesel	20T 2.0 EDC 15M		Live Parameters	13	Actual fuel quantity
Rover	45	Engine Diesel	20T 2.0 EDC 15M		Live Parameters	14	Fuel quantity limit for current engine conditions
Rover	45	Engine Diesel	20T 2.0 EDC 15M		Live Parameters	15	Fuel quantity smoke limit
Rover	45	Engine Diesel	20T 2.0 EDC 15M		Live Parameters	16	Fuel quantity idle control limit
Rover	45	Engine Diesel	20T 2.0 EDC 15M		Live Parameters	17	AC switch
Rover	45	Engine Diesel	20T 2.0 EDC 15M		Live Parameters	18	AC compressor
Rover	45	Engine Diesel	20T 2.0 EDC 15M		Live Parameters	19	Evaporator, air conditioning
Rover	45	Engine Diesel	20T 2.0 EDC 15M		Live Parameters	20	Refrigerant pressure, A/C
Rover	45	Engine Diesel	20T 2.0 EDC 15M		Live Parameters	21	A/C request fan speed
Rover	45	Engine Diesel	20T 2.0 EDC 15M		Live Parameters	22	A/C actual fan speed
Rover	45	Engine Diesel	20T 2.0 EDC 15M		Live Parameters	23	A/C idle speed setpoint
Rover	45	Engine Diesel	20T 2.0 EDC 15M		Live Parameters	24	Idle switch
Rover	45	Engine Diesel	20T 2.0 EDC 15M		Live Parameters	25	Diagnosis lamp
Rover	45	Engine Diesel	20T 2.0 EDC 15M		Live Parameters	26	Brake switch
Rover	45	Engine Diesel	20T 2.0 EDC 15M		Live Parameters	27	Glow time lamp
Rover	45	Engine Diesel	20T 2.0 EDC 15M		Live Parameters	28	Glowplug relay
Rover	45	Engine Diesel	20T 2.0 EDC 15M		Live Parameters	29	Battery voltage
Rover	45	Engine Diesel	20T 2.0 EDC 15M		Live Parameters	30	Accelerator pedal position sensor
Rover	45	Engine Diesel	20T 2.0 EDC 15M		Live Parameters	31	Accelerator pedal position sensor
Rover	45	Engine Diesel	20T 2.0 EDC 15M		Live Parameters	32	Coolant temperature
Rover	45	Engine Diesel	20T 2.0 EDC 15M		Live Parameters	33	Inlet air temperature
Rover	45	Engine Diesel	20T 2.0 EDC 15M		Live Parameters	34	Inlet manifold pressure
Rover	45	Engine Diesel	20T 2.0 EDC 15M		Live Parameters	35	Atmospheric pressure
Rover	45	Engine Diesel	20T 2.0 EDC 15M		Live Parameters	36	Fuel temperature
Rover	45	Engine Petrol	14K4 1.4 Mems 3		ECU Information	1	Ignition coil 1
Rover	45	Engine Petrol	16K4 1.6 Mems 3		ECU Information	1	Ignition coil 1
Rover	45	Engine Petrol	18K4 1.8 Mems 3		ECU Information	1	Ignition coil 1
Rover	75	Brake System	ABS TCS		Live Parameters	1	Front left wheel speed sensor
Rover	75	Brake System	ABS TCS		Live Parameters	2	Front right wheel speed sensor
Rover	75	Brake System	ABS TCS		Live Parameters	3	Rear left wheel speed sensor
Rover	75	Brake System	ABS TCS		Live Parameters	4	Rear right wheel speed sensor
Rover	75	Brake System	ABS TCS		Live Parameters	5	Brake light switch
Rover	75	Climate Control	Climate Control System		Live Parameters	1	Road speed signal
Rover	75	Climate Control	Climate Control System		Live Parameters	2	Ambient temperature
Rover	75	Climate Control	Climate Control System		Live Parameters	3	Automatic Climate System
Rover	75	Climate Control	Climate Control System		Live Parameters	4	AC compressor
Rover	75	Climate Control	Climate Control System		Live Parameters	5	Compartment temperature
Rover	75	Climate Control	Climate Control System		Live Parameters	6	Evaporator temperature
Rover	75	Climate Control	Climate Control System		Live Parameters	7	Recirculation
Rover	75	Climate Control	Climate Control System		Live Parameters	8	Blower speed
Rover	75	Climate Control	Climate Control System		Live Parameters	9	Sun sensor left cell
Rover	75	Climate Control	Climate Control System		Live Parameters	10	Sun sensor right cell
Rover	75	Climate Control	Climate Control System		Live Parameters	11	Temperature control, left side
Rover	75	Climate Control	Climate Control System		Live Parameters	12	Temperature control, right side
Rover	75	Climate Control	Climate Control System		Live Parameters	13	Air distribution, target value
Rover	75	Climate Control	Climate Control System		Live Parameters	14	Air distribution, actual value
Rover	75	Climate Control	Climate Control System		Live Parameters	15	Driver blend, target value
Rover	75	Climate Control	Climate Control System		Live Parameters	16	Passenger blend, target value
Rover	75	Climate Control	Climate Control System		Live Parameters	17	Left hand blending flap potentiometer

Rover	75	Climate Control	Climate Control System	Live Parameters	18	Right hand blending flap potentiometer
Rover	75	Engine Diesel	M47R 2,0 Bosch DDE 4	Live Parameters	1	Fuel rail pressure (low pressure)
Rover	75	Engine Diesel	M47R 2,0 Bosch DDE 4	Live Parameters	2	Accelerator pedal sensor 1
Rover	75	Engine Diesel	M47R 2,0 Bosch DDE 4	Live Parameters	3	Accelerator pedal sensor 2
Rover	75	Engine Diesel	M47R 2,0 Bosch DDE 4	Live Parameters	4	Revolution signal
Rover	75	Engine Diesel	M47R 2,0 Bosch DDE 4	Live Parameters	5	Coolant temperature
Rover	75	Engine Diesel	M47R 2,0 Bosch DDE 4	Live Parameters	6	Inlet air temperature
Rover	75	Engine Diesel	M47R 2,0 Bosch DDE 4	Live Parameters	7	Inlet manifold pressure
Rover	75	Engine Diesel	M47R 2,0 Bosch DDE 4	Live Parameters	8	Airflow
Rover	75	Engine Diesel	M47R 2,0 Bosch DDE 4	Live Parameters	9	Fuel rail pressure (high pressure)
Rover	75	Engine Diesel	M47R 2,0 Bosch DDE 4	Live Parameters	10	Fuel pressure regulator
Rover	75	Engine Diesel	M47R 2,0 Bosch DDE 4	Live Parameters	11	Accelerator pedal sensor 1
Rover	75	Engine Diesel	M47R 2,0 Bosch DDE 4	Live Parameters	12	Accelerator pedal sensor 2
Rover	75	Engine Diesel	M47R 2,0 Bosch DDE 4	Live Parameters	13	Battery voltage
Rover	75	Engine Diesel	M47R 2,0 Bosch DDE 4	Live Parameters	14	Power supply sensor circuit 1
Rover	75	Engine Diesel	M47R 2,0 Bosch DDE 4	Live Parameters	15	Power supply sensor circuit 2
Rover	75	Engine Diesel	M47R 2,0 Bosch DDE 4	Live Parameters	16	Capacitor 1
Rover	75	Engine Diesel	M47R 2,0 Bosch DDE 4	Live Parameters	17	Capacitor 2
Rover	75	Engine Diesel	M47R 2,0 Bosch DDE 4	Live Parameters	18	Road speed signal
Rover	75	Engine Diesel	M47R 2,0 Bosch DDE 4	Live Parameters	19	Brake pedal switch 1
Rover	75	Engine Diesel	M47R 2,0 Bosch DDE 4	Live Parameters	20	Brake pedal switch 2
Rover	75	Engine Diesel	M47R 2,0 Bosch DDE 4	Live Parameters	21	Gear selector connector
Rover	75	Engine Diesel	M47R 2,0 Bosch DDE 4	Live Parameters	22	Clutch pedal switch
Rover	75	Engine Diesel	M47R 2,0 Bosch DDE 4	Live Parameters	23	Cruise control
Rover	75	Engine Petrol	18K4F 1,8 Mems 3	ECU Information	1	Ignition coil 1
Rover	75	Engine Petrol	KV6 2,5 Siemens EMS 2000	Live Parameters	1	Engine torque
Rover	75	Engine Petrol	KV6 2,5 Siemens EMS 2000	Live Parameters	2	Crankshaft signal
Rover	75	Engine Petrol	KV6 2,5 Siemens EMS 2000	Live Parameters	3	Throttle fault indication (info to ABS)
Rover	75	Engine Petrol	KV6 2,5 Siemens EMS 2000	Live Parameters	4	Malfunction indicator lamp (ML)
Rover	75	Engine Petrol	KV6 2,5 Siemens EMS 2000	Live Parameters	5	Cruise control
Rover	75	Engine Petrol	KV6 2,5 Siemens EMS 2000	Live Parameters	6	Fuel pump relay
Rover	75	Engine Petrol	KV6 2,5 Siemens EMS 2000	Live Parameters	7	Throttle switch [input signal]
Rover	75	Engine Petrol	KV6 2,5 Siemens EMS 2000	Live Parameters	8	Throttle position sensor status
Rover	75	Engine Petrol	KV6 2,5 Siemens EMS 2000	Live Parameters	9	Fuel pump
Rover	75	Engine Petrol	KV6 2,5 Siemens EMS 2000	Live Parameters	10	Carbon filter solenoid valve relay
Rover	75	Engine Petrol	KV6 2,5 Siemens EMS 2000	Live Parameters	11	Road speed signal
Rover	75	Engine Petrol	KV6 2,5 Siemens EMS 2000	Live Parameters	12	Air inlet temperature sensor
Rover	75	Engine Petrol	KV6 2,5 Siemens EMS 2000	Live Parameters	13	Coolant temperature sensor
Rover	75	Engine Petrol	KV6 2,5 Siemens EMS 2000	Live Parameters	14	Injection valve 1
Rover	75	Engine Petrol	KV6 2,5 Siemens EMS 2000	Live Parameters	15	Injection valve 2
Rover	75	Engine Petrol	KV6 2,5 Siemens EMS 2000	Live Parameters	16	Injection valve 3
Rover	75	Engine Petrol	KV6 2,5 Siemens EMS 2000	Live Parameters	17	Injection valve 4
Rover	75	Engine Petrol	KV6 2,5 Siemens EMS 2000	Live Parameters	18	Injection valve 5
Rover	75	Engine Petrol	KV6 2,5 Siemens EMS 2000	Live Parameters	19	Injection valve 6
Rover	75	Engine Petrol	KV6 2,5 Siemens EMS 2000	Live Parameters	20	Camshaft signal
Rover	75	Engine Petrol	KV6 2,5 Siemens EMS 2000	Live Parameters	21	Limp home (camshaft sensor)
Rover	75	Engine Petrol	KV6 2,5 Siemens EMS 2000	Live Parameters	22	Limp home (crankshaft sensor)
Rover	75	Engine Petrol	KV6 2,5 Siemens EMS 2000	Live Parameters	23	MAP sensor
Rover	75	Engine Petrol	KV6 2,5 Siemens EMS 2000	Live Parameters	24	Limp home (manifold absolute pressure)
Rover	75	Engine Petrol	KV6 2,5 Siemens EMS 2000	Live Parameters	25	CAN: Communication, engine - ABS
Rover	75	Engine Petrol	KV6 2,5 Siemens EMS 2000	Live Parameters	26	CAN: communication AT
Rover	75	Engine Petrol	KV6 2,5 Siemens EMS 2000	Live Parameters	27	CAN: Communication, engine - instruments
Rover	75	Engine Petrol	KV6 2,5 Siemens EMS 2000	Live Parameters	28	Ignition switch status
Rover	75	Engine Petrol	KV6 2,5 Siemens EMS 2000	Live Parameters	29	Engine status
Rover	75	Engine Petrol	KV6 2,5 Siemens EMS 2000	Live Parameters	30	Cooling fan
Rover	75	Engine Petrol	KV6 2,5 Siemens EMS 2000	Live Parameters	31	A/C clutch
Rover	75	Engine Petrol	KV6 2,5 Siemens EMS 2000	Live Parameters	32	AC requested
Rover	75	Engine Petrol	KV6 2,5 Siemens EMS 2000	Live Parameters	33	AC-relay
Rover	75	Engine Petrol	KV6 2,5 Siemens EMS 2000	Live Parameters	34	Indication rich mixture bank 1
Rover	75	Engine Petrol	KV6 2,5 Siemens EMS 2000	Live Parameters	35	Indication rich mixture bank 2
Rover	75	Engine Petrol	KV6 2,5 Siemens EMS 2000	Live Parameters	36	Lambda regulation, bank 1
Rover	75	Engine Petrol	KV6 2,5 Siemens EMS 2000	Live Parameters	37	Lambda regulation, bank 2
Rover	75	Engine Petrol	KV6 2,5 Siemens EMS 2000	Live Parameters	38	Variable intake balance valve
Rover	75	Engine Petrol	KV6 2,5 Siemens EMS 2000	Live Parameters	39	Variable intake butterfly valve
Rover	75	Engine Petrol	KV6 2,5 Siemens EMS 2000	Live Parameters	40	Drive variable intake valve (balance valve)
Rover	75	Engine Petrol	KV6 2,5 Siemens EMS 2000	Live Parameters	41	Drive variable intake valve (butterfly valve)
Rover	75	Engine Petrol	KV6 2,5 Siemens EMS 2000	Live Parameters	42	Synchronisation camshaft signal
Rover	75	Engine Petrol	KV6 2,5 Siemens EMS 2000	Live Parameters	43	Ambient temperature
Rover	75	Engine Petrol	KV6 2,5 Siemens EMS 2000	Live Parameters	44	Inlet air temperature
Rover	75	Engine Petrol	KV6 2,5 Siemens EMS 2000	Live Parameters	45	Input air temperature [input signal]
Rover	75	Engine Petrol	KV6 2,5 Siemens EMS 2000	Live Parameters	46	Coolant temperature
Rover	75	Engine Petrol	KV6 2,5 Siemens EMS 2000	Live Parameters	47	Coolant temperature [input signal]
Rover	75	Engine Petrol	KV6 2,5 Siemens EMS 2000	Live Parameters	48	Accelerator pedal position
Rover	75	Engine Petrol	KV6 2,5 Siemens EMS 2000	Live Parameters	49	Throttle [input signal]
Rover	75	Engine Petrol	KV6 2,5 Siemens EMS 2000	Live Parameters	50	Knock control bank 2
Rover	75	Engine Petrol	KV6 2,5 Siemens EMS 2000	Live Parameters	51	Knock control bank 1
Rover	75	Engine Petrol	KV6 2,5 Siemens EMS 2000	Live Parameters	52	Knock sensor
Rover	75	Engine Petrol	KV6 2,5 Siemens EMS 2000	Live Parameters	53	Upstream O2 sensor (bank 1)
Rover	75	Engine Petrol	KV6 2,5 Siemens EMS 2000	Live Parameters	54	Upstream O2 sensor (bank 2)
Rover	75	Engine Petrol	KV6 2,5 Siemens EMS 2000	Live Parameters	55	Rear lambda sensor
Rover	75	Engine Petrol	KV6 2,5 Siemens EMS 2000	Live Parameters	56	Upstream O2 sensor heater (bank 2)
Rover	75	Engine Petrol	KV6 2,5 Siemens EMS 2000	Live Parameters	57	Rear lambda sensor, pre-heating
Rover	75	Engine Petrol	KV6 2,5 Siemens EMS 2000	Live Parameters	58	Upstream O2 sensor heater (bank 1)
Rover	75	Engine Petrol	KV6 2,5 Siemens EMS 2000	Live Parameters	59	Idle speed stepper motor (actual value)
Rover	75	Engine Petrol	KV6 2,5 Siemens EMS 2000	Live Parameters	60	Idle speed stepper motor (target value)
Rover	75	Engine Petrol	KV6 2,5 Siemens EMS 2000	Live Parameters	61	Idle speed, target value
Rover	75	Engine Petrol	KV6 2,5 Siemens EMS 2000	Live Parameters	62	Throttle adaption (min value)
Rover	75	Engine Petrol	KV6 2,5 Siemens EMS 2000	Live Parameters	63	Common ignition angle
Rover	75	Engine Petrol	KV6 2,5 Siemens EMS 2000	Live Parameters	64	Ignition angle cylinder 1
Rover	75	Engine Petrol	KV6 2,5 Siemens EMS 2000	Live Parameters	65	Ignition angle cylinder 2
Rover	75	Engine Petrol	KV6 2,5 Siemens EMS 2000	Live Parameters	66	Ignition angle cylinder 3
Rover	75	Engine Petrol	KV6 2,5 Siemens EMS 2000	Live Parameters	67	Ignition angle cylinder 4
Rover	75	Engine Petrol	KV6 2,5 Siemens EMS 2000	Live Parameters	68	Ignition angle cylinder 5
Rover	75	Engine Petrol	KV6 2,5 Siemens EMS 2000	Live Parameters	69	Ignition angle cylinder 6
Rover	75	Engine Petrol	KV6 2,5 Siemens EMS 2000	Live Parameters	70	Fuelling adaption short bank 1
Rover	75	Engine Petrol	KV6 2,5 Siemens EMS 2000	Live Parameters	71	Fuelling adaption short bank 2
Rover	75	Engine Petrol	KV6 2,5 Siemens EMS 2000	Live Parameters	72	Average fuelling adaption short bank 1
Rover	75	Engine Petrol	KV6 2,5 Siemens EMS 2000	Live Parameters	73	Average fuelling adaption short bank 2
Rover	75	Engine Petrol	KV6 2,5 Siemens EMS 2000	Live Parameters	74	Average fuelling adaption short bank 1 & 2
Rover	75	Engine Petrol	KV6 2,5 Siemens EMS 2000	Live Parameters	75	Multiplicative fuelling adaption long bank 1
Rover	75	Engine Petrol	KV6 2,5 Siemens EMS 2000	Live Parameters	76	Multiplicative fuelling adaption long bank 2
Rover	75	Engine Petrol	KV6 2,5 Siemens EMS 2000	Live Parameters	77	Additive fuelling adaption long bank 1
Rover	75	Engine Petrol	KV6 2,5 Siemens EMS 2000	Live Parameters	78	Additive fuelling adaption long bank 2

Rover	75	Engine Petrol	KV6 2.5 Siemens EMS 2000	Live Parameters	79	Engine speed
Rover	75	Engine Petrol	KV6 2.5 Siemens EMS 2000	Live Parameters	80	Road speed signal
Rover	75	Engine Petrol	KV6 2.5 Siemens EMS 2000	Live Parameters	81	Battery voltage
Rover	75	Engine Petrol	KV6 2.5 Siemens EMS 2000	Live Parameters	82	Inlet manifold pressure
Rover	75	Engine Petrol	KV6 2.5 Siemens EMS 2000	Live Parameters	83	Carbon filter solenoid valve
Rover	75	Engine Petrol	KV6 2.5 Siemens EMS 2000	Live Parameters	84	Air mass meter
Rover	75	Engine Petrol	KV6 2.5 Siemens EMS 2000	Live Parameters	85	Injection time bank 1
Rover	75	Engine Petrol	KV6 2.5 Siemens EMS 2000	Live Parameters	86	Injection time bank 2
Rover	75	Engine Petrol	KV6 2.5 Siemens EMS 2000	Live Parameters	87	Immobiliser activated
Rover	75	Engine Petrol	KV6 2.5 Siemens EMS 2000	Live Parameters	88	Communication fault with immobiliser control unit
Rover	75	Engine Petrol	KV6 2.5 Siemens EMS 2000	Live Parameters	89	Ignition on
Rover	75	Engine Petrol	KV6 2.5 Siemens EMS 2000	Live Parameters	90	Immobilisation status
Rover	75	Engine Petrol	KV6 2.5 Siemens EMS 2000	Live Parameters	91	Vehicle status (immobiliser)
Rover	75	Engine Petrol	KV6 2.5 Siemens EMS 2000	Live Parameters	92	Adaption balance wheel
Rover	75	Engine Petrol	KV6 2.5 Siemens EMS 2000	Live Parameters	93	Misfire cyl. 1
Rover	75	Engine Petrol	KV6 2.5 Siemens EMS 2000	Live Parameters	94	Misfire cyl. 2
Rover	75	Engine Petrol	KV6 2.5 Siemens EMS 2000	Live Parameters	95	Misfire cyl. 3
Rover	75	Engine Petrol	KV6 2.5 Siemens EMS 2000	Live Parameters	96	Misfire cyl. 4
Rover	75	Engine Petrol	KV6 2.5 Siemens EMS 2000	Live Parameters	97	Misfire cyl. 5
Rover	75	Engine Petrol	KV6 2.5 Siemens EMS 2000	Live Parameters	98	Misfire cyl. 6
Rover	75	Gearbox / Automatic Transmission	JATCO	Live Parameters	1	ATF temperature
Rover	75	Gearbox / Automatic Transmission	JATCO	Live Parameters	2	Engine speed
Rover	75	Gearbox / Automatic Transmission	JATCO	Live Parameters	3	Torque converter speed
Rover	75	Gearbox / Automatic Transmission	JATCO	Live Parameters	4	Inter Speed
Rover	75	Gearbox / Automatic Transmission	JATCO	Live Parameters	5	Output speed
Rover	75	Gearbox / Automatic Transmission	JATCO	Live Parameters	6	Engine torque
Rover	75	Gearbox / Automatic Transmission	JATCO	Live Parameters	7	Line pressure
Rover	75	Gearbox / Automatic Transmission	JATCO	Live Parameters	8	Lock up pressure
Rover	75	Gearbox / Automatic Transmission	JATCO	Live Parameters	9	Brake Pressure
Rover	75	Gearbox / Automatic Transmission	JATCO	Live Parameters	10	Throttle
Rover	75	Gearbox / Automatic Transmission	JATCO	Live Parameters	11	Coolingfan (high temp automatic transmission fluid)
Rover	75	Gearbox / Automatic Transmission	JATCO	Live Parameters	12	Brake switch
Rover	75	Gearbox / Automatic Transmission	JATCO	Live Parameters	13	Cruise Control Input Circuit
Rover	75	Gearbox / Automatic Transmission	JATCO	Live Parameters	14	Sport program
Rover	75	Gearbox / Automatic Transmission	JATCO	Live Parameters	15	Winter program
Rover	75	Gearbox / Automatic Transmission	JATCO	Live Parameters	16	Normal switch
Rover	75	Gearbox / Automatic Transmission	JATCO	Live Parameters	17	Ignition switch status
Rover	75	Gearbox / Automatic Transmission	JATCO	Live Parameters	18	Fault codes in gearbox control unit
Rover	75	Gearbox / Automatic Transmission	JATCO	Live Parameters	19	A Shift Solenoid
Rover	75	Gearbox / Automatic Transmission	JATCO	Live Parameters	20	B Shift Solenoid
Rover	75	Gearbox / Automatic Transmission	JATCO	Live Parameters	21	C Shift Solenoid
Rover	75	Gearbox / Automatic Transmission	JATCO	Live Parameters	22	Low clutch solenoid
Rover	75	Gearbox / Automatic Transmission	JATCO	Live Parameters	23	Reduction solenoid
Rover	75	Gearbox / Automatic Transmission	JATCO	Live Parameters	24	Brake solenoid
Rover	75	Gearbox / Automatic Transmission	JATCO	Live Parameters	25	Current gear
Rover	75	Gearbox / Automatic Transmission	JATCO	Live Parameters	26	Gear selector
Rover	75	Gearbox / Automatic Transmission	JATCO	Live Parameters	27	Driving mode
Rover	75	Immobiliser	EWS3	Live Parameters	1	Key in ignition
Rover	75	Immobiliser	EWS3	Live Parameters	2	Identification of key
Rover	75	Immobiliser	EWS3	Live Parameters	3	Ignition status
Rover	75	Immobiliser	EWS3	Live Parameters	4	Instrument pack ignition
Rover	75	Immobiliser	EWS3	Live Parameters	5	Key (transponder) status
Rover	75	Immobiliser	EWS3	Live Parameters	6	Engine speed
Rover	75	Immobiliser	EWS3	Live Parameters	7	Automatic gearbox
Rover	75	Immobiliser	EWS3	Live Parameters	8	Superlocked
Rover	75	Immobiliser	EWS3	Live Parameters	9	Immobiliser
Rover	75	Immobiliser	EWS3	Live Parameters	10	Transponder 1
Rover	75	Immobiliser	EWS3	Live Parameters	11	Transponder 1
Rover	75	Immobiliser	EWS3	Live Parameters	12	Transponder 2
Rover	75	Immobiliser	EWS3	Live Parameters	13	Transponder 2
Rover	75	Immobiliser	EWS3	Live Parameters	14	Transponder 3
Rover	75	Immobiliser	EWS3	Live Parameters	15	Transponder 3
Rover	75	Immobiliser	EWS3	Live Parameters	16	Transponder 4
Rover	75	Immobiliser	EWS3	Live Parameters	17	Transponder 4
Rover	75	Immobiliser	EWS3	Live Parameters	18	Transponder 5
Rover	75	Immobiliser	EWS3	Live Parameters	19	Transponder 5
Rover	75	Immobiliser	EWS3	Live Parameters	20	Transponder 6
Rover	75	Immobiliser	EWS3	Live Parameters	21	Transponder 6
Rover	75	Immobiliser	EWS3	Live Parameters	22	Transponder 7
Rover	75	Immobiliser	EWS3	Live Parameters	23	Transponder 7
Rover	75	Immobiliser	EWS3	Live Parameters	24	Transponder 8
Rover	75	Immobiliser	EWS3	Live Parameters	25	Transponder 8
Rover	75	Immobiliser	EWS3	Live Parameters	26	Transponder 9
Rover	75	Immobiliser	EWS3	Live Parameters	27	Transponder 9
Rover	75	Immobiliser	EWS3	Live Parameters	28	Transponder 10
Rover	75	Immobiliser	EWS3	Live Parameters	29	Transponder 10
Rover	75	Immobiliser	GM6	Live Parameters	1	Remote key 1
Rover	75	Immobiliser	GM6	Live Parameters	2	Remote key 2
Rover	75	Immobiliser	GM6	Live Parameters	3	Remote key 3
Rover	75	Immobiliser	GM6	Live Parameters	4	Remote key 4
Rover	75	Immobiliser	GM6	Live Parameters	5	Remote key 5
Rover	75	Immobiliser	GM6	Live Parameters	6	Locking/unlocking button from inside
Rover	75	Immobiliser	GM6	Live Parameters	7	Driver door key lock switch
Rover	75	Immobiliser	GM6	Live Parameters	8	Switch in lock cylinder, luggage space
Rover	75	Immobiliser	GM6	Live Parameters	9	Trunk opening switch
Rover	75	Immobiliser	GM6	Live Parameters	10	Boot lid
Rover	75	Immobiliser	GM6	Live Parameters	11	Hood switch
Rover	75	Immobiliser	GM6	Live Parameters	12	Ignition lock status; auxiliary sense
Rover	75	Immobiliser	GM6	Live Parameters	13	Inertia switch
Rover	75	Immobiliser	GM6	Live Parameters	14	Driver's door
Rover	75	Immobiliser	GM6	Live Parameters	15	Passenger door
Rover	75	Immobiliser	GM6	Live Parameters	16	Right rear door
Rover	75	Immobiliser	GM6	Live Parameters	17	Left rear door
Rover	75	Immobiliser	GM6	Live Parameters	18	Battery voltage
Rover	75	Immobiliser	GM6	Live Parameters	19	Vehicle speed
Rover	75	Instrument / Dashboard	Dashboard	Live Parameters	1	Battery voltage
Rover	75	Instrument / Dashboard	Dashboard	Live Parameters	2	Road speed signal
Rover	75	Instrument / Dashboard	Dashboard	Live Parameters	3	Fuel level sensor (500=Full 22=Empty)
Rover	75	Instrument / Dashboard	Dashboard	Live Parameters	4	Outside temperature sensor
Rover	75	Instrument / Dashboard	Dashboard	Live Parameters	5	RPM-gauge
Rover	75	Instrument / Dashboard	Dashboard	Live Parameters	6	Fuel consumption
Rover	75	Instrument / Dashboard	Dashboard	Live Parameters	7	Indication screenwasher fluid level
Rover	75	Instrument / Dashboard	Dashboard	Live Parameters	8	Brake control lamp

Rover	75	Instrument / Dashboard	Dashboard	Live Parameters	9	Ignition lock status; crank sense
Rover	75	Instrument / Dashboard	Dashboard	Live Parameters	10	Oil pressure
Rover	75	Instrument / Dashboard	Dashboard	Live Parameters	11	Belt buckle switch
Rover	75	Instrument / Dashboard	Dashboard	Live Parameters	12	Indication engine coolant level
Rover	75	Instrument / Dashboard	Dashboard	Live Parameters	13	Fuel pressure when the engine was cut-off
Rover	75	Instrument / Dashboard	Dashboard	Live Parameters	14	Ignition lock status; auxiliary sense
Rover	75	Instrument / Dashboard	Dashboard	Live Parameters	15	Ignition lock status; ignition sense
Rover	75	Instrument / Dashboard	Dashboard	Live Parameters	16	Brake lining indicator
Rover	75	Instrument / Dashboard	Dashboard	Live Parameters	17	Hand brake
Rover	75	Instrument / Dashboard	Dashboard	Live Parameters	18	Trip meter
Rover	75	Instrument / Dashboard	Dashboard	Live Parameters	19	Reset button, trip meter
Rover	75	Instrument / Dashboard	Dashboard	Live Parameters	20	Battery charge
Rover	75	Instrument / Dashboard	Dashboard	Live Parameters	21	SRS warning lamp
Rover	75	Instrument / Dashboard	Dashboard	Live Parameters	22	Check ABS-lamp
Rover	800	Brake System	ABS 5.0	ECU Information	1	Component
Rover	200 III	Brake System	ABS 5.0	ECU Information	1	Component
Rover	400 II	Brake System	ABS 5.0	ECU Information	1	Component